

# Cleaning guidelines for Spectra

## **Cleaning the Coffee Outlet**

To remove the Coffee Outlet gently squeeze tabs located on either side of the outlet and pull downwards. Remove rubber piece and clean with cool water and brushes ensuring all holes are free of blockages. Clean the outlet where the parts have been removed from. Replace rubber part into the coffee outlet. Replace coffee outlet by placing up into the machine until the tabs click into place.

## **Daily Cleaning procedure**

1. Empty milk container and fill with 1 litres of cold water.
2. Gently press and hold the clean button on top panel of the machine. Display will read empty drawer, open door promptly at bottom of the machine and empty dregs drawer, clean under and around the drawer area.
3. Using keys at top of door, open front panel of the machine. Remove the Chocolate whipper by pushing grey tap (some tabs may be red) anti-clockwise, clean thoroughly and dry completely and replace ensuring tab is turned clockwise until it clicks. Close panel and turn key to lock. (note; the dregs door needs to be open for a minimum 2 minutes or the machine will not register the cleaning cycle)
4. Place dregs drawer back inside and close the door.
5. Machine will then prompt to insert cleaning tablet, take one tablet insert into chute at the top of the machine.
6. Place the milk container with water inside and 30 mls of cleaning solution inside the fridge and ensure milk tube is inside the container.
7. Press clean again. Machine will then begin a cleaning cycle.
8. When the display prompts Fill Water, remove the milk container and empty, fill with cold clean water. Replace the container in the fridge and ensure tube is inside. Press clean again.
9. Machine will display Please Select when cleaning cycle is finished.
10. Wash the drip tray and pour hot water down the drain.
11. Turn the machine off.

## **Cleaning the bean hopper**

Turn off machine and wipe inside of bean hopper with a clean dry cloth or paper towel. Fill with fresh beans.

## **Cleaning the piston head**

Open the door with keys and remove the dregs drawer. Using the piston head brush or a dry cloth wipe away all coffee granules that have gathered on the piston head.

## **Cleaning the Fridge unit**

Remove the milk container and clean. Using a damp cloth wipe the interior of the Fridge unit paying particular attention to the door seals, ensure all milk deposits are cleaned away.

**Before commencing use of this machine please make one milky drink and discard.**

