

FLAIR COFFEE MACHINE DE-SCALING PROCEDURE

De-scaling is a necessary part of looking after your coffee machine. It removes unnecessary limescale from the machine pipework thus preventing loss in water temperature & taste issues.

Frequency: The frequency that this procedure should be carried out will depend on water hardness levels in your area. The machine will prompt for de-scaling. The following message appears in the display area DECALCIFYING NECESSARY.

NB: Once started, the cleaning procedure may not be stopped. The procedure takes approximately 60 minutes.

1. Switch on the Unit at the ON/OFF button.
2. Press and hold the descaling button (blue button under display) until an acoustic signal is heard.



Press & hold until signal is heard

3. The display reads : EMPTY DRIP TRAY. Remove the drip tray and empty.
4. The display reads : EMPTY DUMP BOX. Remove the dump box and empty. Re-insert the dump box & then the drip tray into the machine when cleaned.
5. The display reads : INSERT AGENT IN WATER TANK. Fill the water tank with 600ml of cold water. Empty the contents of one sachet of *Dezcal* descaler (Bewleys part number OSP3022) into the water. Stir until completely dissolved.
6. Press the de-scale button.



Press to continue

7. The machine will now go through the de-scaling cycle. The display will read : UNIT DECALCIFYING for the duration of the de-scale.

8. After a period the machine will prompt to fill the water tank with fresh water. If necessary empty out any remaining liquid from the water tank. Fill the water tank with 600ml of cold water.
9. Press the de-scale button.



Press to continue

The machine will now continue through the de-scaling cycle. The display will read :
UNIT DECALCIFYING for the duration of the de-scale.

10. When completed the machine will prompt you to EMPTY DRIP TRAY . Remove the drip tray and empty.
11. The display reads : EMPTY DUMP BOX. Remove the dump box and empty.
12. Re-insert the dump box and then the drip tray into the machine when cleaned. Also clean the base of the coffee machine before re-inserting the drip tray and dump box into the machine.
13. The display reads : SELECT PRODUCT. The de-scaling cycle is now complete and the machine ready for use.